

INSTALLATION INSTRUCTION

HEATKING WALL MOUNTING BRACKET KIT: 70400416 & 70400417

| ITEM | QUANTITY | DESCRIPTION |
|------|----------|--------------------------|
| 1 | 4 | M10 RAWLBOLT |
| 2 | 4 | PIN (wall mtg bkt) BWARM |
| 3 | 4 | PIN 2.0mm RETAINER |
| 4 | 4 | M8 NUT |
| 5 | 4 | M8 SPRING WASHER |
| 6 | 4 | M8x21 WASHER |
| 7 | 10 | M8x32 WASHER |

Ensure that the wall to accept brackets is flat, perpendicular and will accept the weight of the unit (85Kg)

- ❑ **BRACKETS** – Assemble as diagram. Fit retaining clips after inserting pins through holes in horizontal and vertical brackets. Brackets with **RED DOT** markers **MUST** be fixed at the right hand (compressor) end of unit.
- ❑ **RAWLBOLTS** – Hole 12mm diameter x 60mm deep. M10 nut (15mm A/F)
- ❑ **UNIT MOUNTING** – Locate unit feet holes on anti-vibration mounts and secure with plain washer, spring washer and M8 nut (13mm A/F)
- ❑ **LEVELING** – It is essential, to minimize the effects of vibration and maximize drainage, if a drain tray is fitted, that the unit is level when fixed to the bracket. Use the large washers, provided loose, to level each corner of the unit if necessary. **DO NOT EXCEED 4 WASHERS PER CORNER.** (see fig 1)

